Task 1: Develop a program that capture 10 Ethernet frames from the network and display the source and destination MAC addresses along with the data in each of the frames.


```
import socket, sys
from struct import *
#Convert a string of 6 characters of ethernet address into a dash
separated hex string
def eth_addr (a) :
    b = \%.2x:\%.2x:\%.2x:\%.2x:\%.2x:\% (ord(a[0]) , ord(a[1]) ,
ord(a[2]), ord(a[3]), ord(a[4]), ord(a[5]))
     return b
#create a AF_PACKET type raw socket (thats basically packet level)
#define ETH_P_ALL
                   0x0003
                                    /* Every packet (be
careful!!!) */
try:
     s = socket.socket( socket.AF_PACKET , socket.SOCK_RAW ,
socket.ntohs(0x0003))
except socket.error , msg:
    print 'Socket could not be created. Error Code : ' +
str(msg[0]) + 'Message' + msg[1]
     sys.exit()
# receive a packet
for i in range(0, 10):
    print
    print '--PACKET '+str(i+1)+'--'
    print
    packet = s.recvfrom(65565)
    #packet string from tuple
    packet = packet[0]
    #parse ethernet header
    eth_length = 14
    eth_header = packet[:eth_length]
    eth = unpack('!6s6sH' , eth_header)
    eth protocol = socket.ntohs(eth[2])
    print 'Destination MAC : ' + eth_addr(packet[0:6]) + ' Source
MAC : ' + eth_addr(packet[6:12]) + ' Protocol : ' +
str(eth_protocol)
    print '--ETHERNET HEADER--'
    #Parse IP header
    #take first 20 characters for the ip header
    ip header = packet[eth length:20+eth length]
    #now unpack them
    iph = unpack('!BBHHHBBH4s4s' , ip_header)
```


```
version ihl = iph[0]
    version = version ihl >> 4
    ihl = version_ihl & 0xF
    iph length = ihl * 4
    ttl = iph[5]
    protocol = iph[6]
    s_addr = socket.inet_ntoa(iph[8]);
    d_addr = socket.inet_ntoa(iph[9]);
    print 'Version : ' + str(version) + ' IP Header Length : ' +
str(ihl) + ' TTL : ' + str(ttl) + ' Protocol : ' + str(protocol) +
' Source Address : ' + str(s addr) + ' Destination Address : ' +
str(d_addr)
    #TCP protocol
    if protocol == 6:
         print '--TCP--'
          t = iph_length + eth_length
          tcp_header = packet[t:t+20]
         #now unpack them :)
          tcph = unpack('!HHLLBBHHH' , tcp_header)
          source_port = tcph[0]
         dest_port = tcph[1]
          sequence = tcph[2]
         acknowledgement = tcph[3]
         doff\ reserved = tcph[4]
          tcph_length = doff_reserved >> 4
         print 'Source Port : ' + str(source_port) + ' Dest Port :
' + str(dest_port) + ' Sequence Number : ' + str(sequence) + '
Acknowledgement : ' + str(acknowledgement) + ' TCP header length :
' + str(tcph_length)
         h size = eth length + iph length + tcph length * 4
         data_size = len(packet) - h_size
         #get data from the packet
         data = packet[h_size:]
         print 'Data : ' + data
    #ICMP Packets
    elif protocol == 1 :
         print '--ICMP--'
         u = iph_length + eth_length
         icmph length = 4
          icmp header = packet[u:u+4]
         #now unpack them :)
```

```
icmph = unpack('!BBH' , icmp_header)
          icmp_type = icmph[0]
          code = icmph[1]
          checksum = icmph[2]
          print 'Type : ' + str(icmp_type) + ' Code : ' + str(code)
+ ' Checksum : ' + str(checksum)
          h_size = eth_length + iph_length + icmph_length
          data_size = len(packet) - h_size
          #get data from the packet
          data = packet[h_size:]
          print 'Data : ' + data
     #UDP packets
     elif protocol == 17 :
          print '--UDP--'
          u = iph_length + eth_length
          udph length = 8
          udp_header = packet[u:u+8]
          #now unpack them :)
          udph = unpack('!HHHH' , udp_header)
          source_port = udph[0]
          dest_port = udph[1]
          length = udph[2]
          checksum = udph[3]
          print 'Source Port : ' + str(source_port) + ' Dest Port :
' + str(dest_port) + ' Length : ' + str(length) + ' Checksum : ' +
str(checksum)
          h size = eth length + iph length + udph length
          data size = len(packet) - h size
          #get data from the packet
          data = packet[h_size:]
          print 'Data : ' + data
     #IGMP packets
     elif protocol == 88 :
          print '--IGMP--'
          u = iph_length + eth_length
          iqmph\_length = 8
          igmp_header = packet[u:u+8]
          #now unpack them :)
          igmph = unpack('!HHHHH' , igmp_header)
```

```
source_port = igmph[0]
          dest_port = igmph[1]
          length = igmph[2]
          checksum = igmph[3]
          print 'Source Port : ' + str(source_port) + ' Dest Port :
' + str(dest_port) + ' Length : ' + str(length) + ' Checksum : ' +
str(checksum)
          h_size = eth_length + iph_length + igmph_length
          data_size = len(packet) - h_size
          #get data from the packet
          data = packet[h_size:]
          print 'Data : ' + data
     #some other IP packet
     else :
          print 'Protocol other than TCP/UDP/ICMP/IGMP'
     print
```

```
1 En ≪× 11:48 AM ☼ c3-13
0
     root@cselab3:/home/c3-137/packets# python 10packets.py
Destination MAC : ff:ff:ff:ff:ff:ff Source MAC : 2c:ab:eb:23:1e:a0 Protocol : 39304
     Version : 2 IP Header Length : 3 TTL : 171 Protocol : 235 Source Address : 160.22.0.0 Destination Address :
     0.0.0.0
Protocol other than TCP/UDP/ICMP/IGMP
     --PACKET 2--
     Destination MAC : ff:ff:ff:ff:ff:ff Source MAC : 00:lc:c0:ll:0d:52 Protocol : 1544
     --ETHERNET HEADER--
Version : 0 IP Header Length : 0 TTL : 0 Protocol : 28 Source Address : 13.82.172.20 Destination Address : 3
.19.0.0
     Protocol other than TCP/UDP/ICMP/IGMP
     --PACKET 3--
     Destination MAC : ff:ff:ff:ff:ff:ff Source MAC : 18:68:cb:98:55:1c Protocol : 1544
--ETHERNET HEADER--
     Version : 0 IP Header Length : 0 TTL : 24 Protocol : 104 Source Address : 85.28.10.10 Destination Address : 11.201.0.0
Protocol other than TCP/UDP/ICMP/IGMP
      --PACKET 4--
     Destination MAC : ff:ff:ff:ff:ff:ff Source MAC : 6c:3b:e5:35:8b:cb Protocol : 8
     --ETHERNET HEADER--
Version : 4 IP Header Length : 5 TTL : 128 Protocol : 17 Source Address : 192.168.25.106 Destination Address
```





Task 2: Develop a program that capture n packets and displays the complete packet details including the headers.

```
import socket, sys
from struct import *
#Convert a string of 6 characters of ethernet address into a dash
separated hex string
def eth_addr (a) :
     b = \%.2x:\%.2x:\%.2x:\%.2x:\%.2x:\% (ord(a[0]) , ord(a[1]) ,
ord(a[2]), ord(a[3]), ord(a[4]), ord(a[5]))
     return b
#create a AF_PACKET type raw socket (thats basically packet level)
#define ETH_P_ALL
                    0x0003
                                     /* Every packet (be
careful!!!) */
try:
     s = socket.socket( socket.AF_PACKET , socket.SOCK_RAW ,
socket.ntohs(0x0003))
except socket.error , msg:
     print 'Socket could not be created. Error Code : ' +
str(msg[0]) + 'Message ' + msg[1]
     sys.exit()
n = input('Enter number of packets you want: ')
# receive a packet
for i in range(0, n):
     print
     print '--PACKET '+str(i+1)+'--'
     print
     packet = s.recvfrom(65565)
     #packet string from tuple
     packet = packet[0]
     #parse ethernet header
     eth_length = 14
     eth header = packet[:eth_length]
     eth = unpack('!6s6sH', eth header)
     eth protocol = socket.ntohs(eth[2])
     print 'Destination MAC : ' + eth_addr(packet[0:6]) + ' Source
MAC : ' + eth_addr(packet[6:12]) + ' Protocol : ' +
str(eth protocol)
     print '--ETHERNET HEADER--'
     #Parse IP header
     #take first 20 characters for the ip header
     ip_header = packet[eth_length:20+eth_length]
     #now unpack them
```

```
iph = unpack('!BBHHHBBH4s4s' , ip_header)
    version_ihl = iph[0]
    version = version_ihl >> 4
    ihl = version ihl & 0xF
    iph_length = ihl * 4
    ttl = iph[5]
    protocol = iph[6]
     s_addr = socket.inet_ntoa(iph[8]);
    d_addr = socket.inet_ntoa(iph[9]);
     print 'Version : ' + str(version) + ' IP Header Length : ' +
str(ihl) + ' TTL : ' + str(ttl) + ' Protocol : ' + str(protocol) +
' Source Address : ' + str(s_addr) + ' Destination Address : ' +
str(d addr)
    #TCP protocol
    if protocol == 6:
         print '--TCP--'
          t = iph_length + eth_length
          tcp_header = packet[t:t+20]
         #now unpack them :)
          tcph = unpack('!HHLLBBHHH' , tcp_header)
         source_port = tcph[0]
         dest_port = tcph[1]
          sequence = tcph[2]
         acknowledgement = tcph[3]
         doff_reserved = tcph[4]
          tcph_length = doff_reserved >> 4
         print 'Source Port : ' + str(source_port) + ' Dest Port :
' + str(dest_port) + ' Sequence Number : ' + str(sequence) + '
Acknowledgement : ' + str(acknowledgement) + ' TCP header length :
' + str(tcph length)
         h_size = eth_length + iph_length + tcph_length * 4
         data_size = len(packet) - h_size
         #get data from the packet
         data = packet[h_size:]
         print 'Data : ' + data
    #ICMP Packets
    elif protocol == 1 :
         print '--ICMP--'
         u = iph length + eth length
          icmph_length = 4
          icmp_header = packet[u:u+4]
```

```
#now unpack them :)
          icmph = unpack('!BBH' , icmp_header)
          icmp_type = icmph[0]
          code = icmph[1]
          checksum = icmph[2]
          print 'Type : ' + str(icmp_type) + ' Code : ' + str(code)
+ ' Checksum : ' + str(checksum)
          h_size = eth_length + iph_length + icmph_length
          data_size = len(packet) - h_size
          #get data from the packet
          data = packet[h_size:]
          print 'Data : ' + data
     #UDP packets
     elif protocol == 17 :
          print '--UDP--'
          u = iph_length + eth_length
          udph\_length = 8
          udp_header = packet[u:u+8]
          #now unpack them :)
          udph = unpack('!HHHH' , udp_header)
          source_port = udph[0]
          dest_port = udph[1]
          length = udph[2]
          checksum = udph[3]
          print 'Source Port : ' + str(source_port) + ' Dest Port :
' + str(dest_port) + ' Length : ' + str(length) + ' Checksum : ' +
str(checksum)
          h_size = eth_length + iph_length + udph_length
          data_size = len(packet) - h_size
          #get data from the packet
          data = packet[h_size:]
          print 'Data : ' + data
     #IGMP packets
     elif protocol == 88 :
          print '--IGMP--'
          u = iph length + eth length
          igmph length = 8
          igmp_header = packet[u:u+8]
```

```
#now unpack them :)
         igmph = unpack('!HHHHH' , igmp_header)
          source_port = igmph[0]
         dest_port = igmph[1]
         length = igmph[2]
         checksum = igmph[3]
         print 'Source Port : ' + str(source_port) + ' Dest Port :
' + str(dest_port) + ' Length : ' + str(length) + ' Checksum : ' +
str(checksum)
         h_size = eth_length + iph_length + igmph_length
         data_size = len(packet) - h_size
         #get data from the packet
         data = packet[h size:]
         print 'Data : ' + data
    #some other IP packet
    else :
         print 'Protocol other than TCP/UDP/ICMP/IGMP'
    print
```

```
root@cselab3: /home/c3-137/packets
                                                                                                                                          1 En ≪× 11:51 AM 🖔 c3-137
 root@cselab3:/home/c3-137/packets# python npackets.py
      Enter number of packets you want: 6
       --PACKET 1--
      Destination MAC : ff:ff:ff:ff:ff:ff Source MAC : 6c:3b:e5:35:8b:fc Protocol : 8
      Version : 4 IP Header Length : 5 TTL : 128 Protocol : 17 Source Address : 192.168.25.105 Destination Address : 192.168.25.255
      Source Port : 137 Dest Port : 137 Length : 58 Checksum : 10557

  翻翻
  DBDJDCCACACACACACACACACACACACACAAA

       --PACKET 2--
       Destination MAC : ff:ff:ff:ff:ff:ff Source MAC : 18:68:cb:98:55:1c Protocol : 1544
      --ETHERNET HEADER--
Version : 0 IP Header Length : 0 TTL : 24 Protocol : 104 Source Address : 85.28.10.10 Destination Address : 11.201.0.0
Protocol other than TCP/UDP/ICMP/IGMP
 a
       --PACKET 3--
      Destination MAC : ff:ff:ff:ff:ff:ff Source MAC : d4:c9:ef:f2:a7:e3 Protocol : 8
--ETHERNET HEADER--
Version : 4 IP Header Length : 5 TTL : 128 Protocol : 17 Source Address : 192.168.25.30 Destination Address : 192.168.25.255
      Source Port : 137 Dest Port : 137 Length : 58 Checksum : 65246
Data : 命價冊 EDEBEECNDDDECACACACACACACABM 圓
       --PACKET 4--
      Destination MAC : ff:ff:ff:ff:ff:ff Source MAC : d4:c9:ef:ef:c6:2b Protocol : 8
--ETHERNET HEADER--
```

```
oot@cselab3: /home/c3-137/packets
     --ETHERNET HEADER--
Version : 4 IP Header Length : 5 TTL : 128 Protocol : 17 Source Address : 192.168.25.30 Destination Address : 192.168.25.255
     --UDP--
     Source Port : 137 Dest Port : 137 Length : 58 Checksum : 65246
Data : ������� EDEBEECNDDDECACACACACACACACABM
      --PACKET 4--
     Destination MAC : ff:ff:ff:ff:ff:ff Source MAC : d4:c9:ef:ef:c6:2b Protocol : 8
     --ETHERNET HEADER--
Version : 4 IP Header Length : 5 TTL : 128 Protocol : 17 Source Address : 172.20.5.159 Destination Address : 172.20.7.255
     Source Port: 138 Dest Port: 138 Length: 219 Checksum: 12190
Data: [[66][66] EJFEEMEBECDDCNDBDBDGCACACACACAAA ABACFPFPENFDECFCEPFHFDEFFPPACAB@SMB%[]6[]47][]*\MAILSLOT\BROWSE
ITLAB3[]
     TOTTLAB3-116
     --PACKET 5--
     Destination MAC : ff:ff:ff:ff:ff:ff Source MAC : 34:64:a9:2b:64:a3 Protocol : 8
--ETHERNET HEADER--
     Version : 4 IP Header Length : 5 TTL : 128 Protocol : 17 Source Address : 172.20.5.80 Destination Address : 172.20.7.255
     --PACKET 6--
Destination MAC : 33:33:00:01:00:03 Source MAC : 78:2b:cb:8d:3e:39 Protocol : 56710
     Version : 6 IP Header Length : 0 TTL : 254 Protocol : 128 Source Address : 0.0.0.0 Destination Address : 149.186.27.148
Protocol other than TCP/UDP/ICMP/IGMP
     root@cselab3:/home/c3-137/packets#
```

Task 3: Write a program to extract and print the TCP segment information including the header.

```
import socket, sys
from struct import *
#Convert a string of 6 characters of ethernet address into a dash
separated hex string
def eth_addr (a) :
     b = \%.2x:\%.2x:\%.2x:\%.2x:\%.2x:\% (ord(a[0]) , ord(a[1]) ,
ord(a[2]), ord(a[3]), ord(a[4]), ord(a[5]))
     return b
#create a AF_PACKET type raw socket (thats basically packet level)
#define ETH_P_ALL
                    0x0003
                                     /* Every packet (be
careful!!!) */
try:
     s = socket.socket( socket.AF_PACKET , socket.SOCK_RAW ,
socket.ntohs(0x0003))
except socket.error , msg:
     print 'Socket could not be created. Error Code : ' +
str(msg[0]) + 'Message' + msg[1]
     sys.exit()
n = input('Enter number of packets you want: ')
# receive a packet
while(i<n):
     packet = s.recvfrom(65565)
```

```
#packet string from tuple
    packet = packet[0]
    #parse ethernet header
    eth_length = 14
    eth_header = packet[:eth_length]
    eth = unpack('!6s6sH', eth_header)
    eth_protocol = socket.ntohs(eth[2])
    #Parse IP header
    #take first 20 characters for the ip header
    ip_header = packet[eth_length:20+eth_length]
    #now unpack them
    iph = unpack('!BBHHHBBH4s4s' , ip_header)
    version_ihl = iph[0]
    version = version_ihl >> 4
    ihl = version_ihl & 0xF
    iph length = ihl * 4
    ttl = iph[5]
    protocol = iph[6]
    s_addr = socket.inet_ntoa(iph[8]);
    d_addr = socket.inet_ntoa(iph[9]);
    #TCP protocol
    if protocol == 6:
         i+=1
         print
          print
         print '--PACKET '+str(i)+'--'
         print 'Destination MAC : ' + eth_addr(packet[0:6]) + '
Source MAC : ' + eth_addr(packet[6:12]) + ' Protocol : ' +
str(eth protocol)
          print '--ETHERNET HEADER--'
         print 'Version : ' + str(version) + ' IP Header Length :
' + str(ihl) + ' TTL : ' + str(ttl) + ' Protocol : ' +
str(protocol) + ' Source Address : ' + str(s_addr) + ' Destination
Address : ' + str(d_addr)
          t = iph_length + eth_length
          tcp_header = packet[t:t+20]
         #now unpack them :)
          tcph = unpack('!HHLLBBHHH' , tcp_header)
          source_port = tcph[0]
         dest port = tcph[1]
          sequence = tcph[2]
          acknowledgement = tcph[3]
```


```
doff_reserved = tcph[4]
    tcph_length = doff_reserved >> 4

    print '--TCP--'
    print 'Source Port : ' + str(source_port) + ' Dest Port :
' + str(dest_port) + ' Sequence Number : ' + str(sequence) + '
Acknowledgement : ' + str(acknowledgement) + ' TCP header length :
' + str(tcph_length)

    h_size = eth_length + iph_length + tcph_length * 4
    data_size = len(packet) - h_size

#get data from the packet
    data = packet[h_size:]

print 'Data : ' + data
```



Task 4: Write a program to extract and print the UDP segment information.

Program:

```
import socket, sys
from struct import *
```

#Convert a string of 6 characters of ethernet address into a dash separated hex string

```
def eth addr (a):
     b = \%.2x:\%.2x:\%.2x:\%.2x:\%.2x:\% (ord(a[0]), ord(a[1]),
ord(a[2]), ord(a[3]), ord(a[4]), ord(a[5]))
     return b
#create a AF_PACKET type raw socket
try:
     s = socket.socket( socket.AF_PACKET , socket.SOCK_RAW ,
socket.ntohs(0x0003))
except socket.error , msg:
     print 'Socket could not be created. Error Code : ' +
str(msq[0]) + 'Message ' + msg[1]
     sys.exit()
n = input('Enter number of packets you want: ')
i = 0
# receive a packet
while(i<n):</pre>
     packet = s.recvfrom(65565)
     #packet string from tuple
     packet = packet[0]
     #parse ethernet header
     eth_length = 14
     eth_header = packet[:eth_length]
     eth = unpack('!6s6sH' , eth_header)
     eth_protocol = socket.ntohs(eth[2])
     #Parse IP header
     #take first 20 characters for the ip header
     ip_header = packet[eth_length:20+eth_length]
     #now unpack them
     iph = unpack('!BBHHHBBH4s4s' , ip_header)
     version ihl = iph[0]
     version = version_ihl >> 4
     ihl = version ihl & 0xF
     iph_length = ihl * 4
     ttl = iph[5]
     protocol = iph[6]
     s_addr = socket.inet_ntoa(iph[8]);
     d addr = socket.inet ntoa(iph[9]);
     if protocol == 17 :
          i+=1
          print
          print
          print '--PACKET '+str(i)+'--'
```


```
print 'Destination MAC : ' + eth_addr(packet[0:6]) + '
Source MAC : ' + eth_addr(packet[6:12]) + ' Protocol : ' +
str(eth_protocol)
          print '--UDP--'
          u = iph_length + eth_length
          udph_length = 8
          udp_header = packet[u:u+8]
          #now unpack them :)
          udph = unpack('!HHHH' , udp_header)
          source_port = udph[0]
          dest_port = udph[1]
          length = udph[2]
          checksum = udph[3]
          print 'Source Port : ' + str(source_port) + ' Dest Port :
' + str(dest_port) + ' Length : ' + str(length) + ' Checksum : ' +
str(checksum)
          h_size = eth_length + iph_length + udph_length
          data_size = len(packet) - h_size
          #get data from the packet
          data = packet[h_size:]
          print 'Data : ' + data
```

Task 5: Write a program that captures 100 packets and display the count of ICMP, IGMP, TCP, UDP, and IP packets.


```
import socket, sys
from struct import *
#Convert a string of 6 characters of ethernet address into a dash
separated hex string
def eth_addr (a) :
     b = \%.2x:\%.2x:\%.2x:\%.2x:\%.2x:\% (ord(a[0]) , ord(a[1]) ,
ord(a[2]), ord(a[3]), ord(a[4]), ord(a[5]))
     return b
#create a AF_PACKET type raw socket
try:
     s = socket.socket( socket.AF_PACKET , socket.SOCK_RAW ,
socket.ntohs(0x0003))
except socket.error , msg:
     print 'Socket could not be created. Error Code : ' +
str(msg[0]) + 'Message ' + msg[1]
     sys.exit()
# receive a packet
icmp = 0
tcp = 0
udp = 0
iqmp = 0
for i in range(0, 1000):
     packet = s.recvfrom(65565)
     #packet string from tuple
     packet = packet[0]
     eth length = 14
     #Parse IP header
     #take first 20 characters for the ip header
     ip_header = packet[eth_length:20+eth_length]
     #now unpack them
     iph = unpack('!BBHHHBBH4s4s' , ip_header)
     ttl = iph[5]
     protocol = iph[6]
     #TCP protocol
     if protocol == 6:
          tcp+=1
     #ICMP Packets
     elif protocol == 1 :
          icmp+=1
     #UDP packets
```

```
elif protocol == 17 :
    udp+=1

#IGMP Packets
elif protocol == 88 :
    igmp+=1
    sys.stdout.write("\rTCP: %d UDP: %d ICMP: %d IGMP: %d Total:
%d" %(tcp, udp, icmp, igmp, i+1))
    sys.stdout.flush()
print
```



For 1000 packets,



For 10,000 packets,

